


Taurus Chain Blocks

Information



No	Parts No	Description	Qty	No	Parts No	Description	Qty		
A	1	Z108	Gear cover	1	C	22	Z717a/b	End anchor	1
	2	Z211a	Support plate assy	1		23	Z707	End spring	1
	3	Z205	(Gear bushing)	2		24	M820	Load chain (VL, VP)	1
	4	Z911	Nut for cover	6		25	H820	Load chain (VH)	1
B	5	Z102a	Side plate (B) assy	1	D	26	Z101a	Side plate (B) assy	1
	6	Z204	Needle bearing	1		27	Z103	(Stay bolt)	3
	7	Z206	1st gear	1		28	Z105	Brake cover	1
	8	Z207	2nd gear	2		29	Z204	Needle bearing	1
	9	Z208	3rd gear	2		30	Z301	Hub	1
	10	Z209	Pinion shaft	1		31	Z302A	Brake disk A	1
	11	Z210	Pinion washer (1/2 ton only)	1		32	Z302B	Brake disk B	1
						33	Z303	Ratchet gear	1
C	12	Z109	Load chain guide	2		34	Z304	Pawl	1
	13	Z110	Chain stripper	1		35	Z305	Spring	1
	14	Z203	Load sheave	1		36	Z306	(Pawl stud)	1
	15	Z701a	Top hook	1		37	Z106	Wheel cover	1
	16	Z709Ha	Bottom hook (VH)	1		38	Z307	Snap ring	1
	17	Z709La	Bottom hook (VL, VP)	1	E	39	Z201	Hand wheel washer	1
	18	Z740a	Safety latch assy	1		40	Z202	Hand wheel	1
	19	Z703	Hook pin	1		41	Z800	Hand chain	1
	20	Z705a	Bolt & nut for load chain	1		42	Z902	Pinion nut	1
	21	Z706	End pin	1		43	Z905	Cotter pin	1